

KUBOTA ZERO-TAIL SWING MINI EXCAVATOR

017-30%



With Kubota's advanced and upgraded U17-3 α , you'll have the versatility and performance to take on almost any task.



KUBOTA ZERO-TAIL SWING MINI-EXCAVATOR

$U17-3\alpha$




DIGITAL PANEL



Informative, interactive and functional. Kubota's Intelligent Control System keeps you in tune of the U17-3 α 's vital signs. It accurately displays easy-to-understand diagnostics of current working conditions and warning indicators for engine rpm and hour meter, as well as for fuel, temperature and oil levels. When filling up with fuel, our panel also informs the operator that the tank is nearly full, and alerts the operator to when routine maintenance is due. Overall, the panel reduces excavator repair time for a decrease in total operating costs.







Language selection display

Information when service is required

Low fuel display



ROPS/FOPS Canopy

Safety first. The canopy conforms to ROPS (Roll-Over Protective Structure) and FOPS (Falling Objects Protective Structure) Level 1 specifications, so that you can concentrate on what's important — your work.

2-Speed Travel Switch on Dozer Lever

The dozer lever features a 2-speed travel switch, which allows the operator to easily select between power or travel speed during levelling work, depending on the load.

Straight Travel

Loading and unloading is safer due to a unique Kubota hydraulic system that provides straight travel, even during simultaneous operations.

Long arm version

Reach further. Dig deeper. Extend your working range, increase your productivity and expand the kinds of jobs you can undertake with the U17-3 α 's long arm version. At an impressive 1100 mm, a full 150 mm longer than the standard arm version, the long arm version offers a surprising reach for an excavator this size. Kubota has also optimized the excavator's weight to ensure reliably stable operation.





The boom cylinder is situated above the boom for maximum protection, especially during breaker or dumping operation. Movement speeds of front attachments and lifting power have been well adjusted, thanks to the boom cylinder's large-diameter rod and optimal hydraulic pressure.

Protected Motor Hoses -

Kubota has enclosed the travel motor hoses within the track frame for added protection—a unique feature for mini excavators of this class.





ANTI-THEFT SYSTEM

The ultimate in security that's as easy as turning a key. It's the industry's first standard-equipped anti-theft system, and another original only from Kubota.



THE SYSTEM

Introducing Kubota's new simple and secure anti-theft system. Our one-key-system has an IC chip, which only starts the engine when the system recognises the appropriate key. Standard equipment includes one Red programming key, plus two Black operational keys. And up to four Black keys can be programmed. What's more, you get peace of mind knowing your construction equipment couldn't be in safer hands.

C EASY OPERATION

No special procedures needed. No PIN numbers needed. Just turn the key. Plus, our simple "one-key-security system" allows access to the cabin door and engine bonnet as well as the fuel tank.

SAFETY/SECURITY

Only "programmed keys" will enable the engine to start. Even identically shaped keys can't start the engine unless they are programmed. In fact, attempting to start the engine with an un-programmed key will activate the system's alarm. This alarm will continue even after the un-programmed key is removed. It will only stop once a programmed key is inserted into the ignition and switched on to start the engine.

EASY PROGRAMMING

One Red programming key and two pre-programmed Black operational keys come standard. If a Black key is misplaced, or if additional Black keys are needed (a maximum of two can be added), key programming is easy. Simply insert the Red key, followed by the Black keys.



Insert the Red programming key, then press the monitor button.



1 Insert new individual Black operational key.

■ Programmed key



Insert key

The excavator moves

■ Un-programmed key



Insert key



The alarm sounds

Standard Equipment

Engine/Fuel System

- Double-element air cleaner
- Electric fuel pump

Undercarriage

- 230 mm rubber track
- 2-speed travel switch on dozer lever
- Variable track
- 3 outer flange-type track rollers on each track

Hydraulic System

- Pressure accumulator
- Hydraulic pressure checking ports
- Straight travel circuit
- Third-line hydraulic return
- Variable displacement pump

Safety System

- Engine Start Safety System on left console
- Travel Lock System on left console
- Swivel Lock System
- Anti-theft system

Working Equipment

- 950 mm arm
- Auxiliary hydraulic circuit piping to arm's end
- Working light on boom

Canopy and Operating Area

• ROPS (Roll-Over Protective Structure, ISO 3471)

- FOPS (Falling Objects Protective Structure) Level 1
- Weight-adjustable, semi-suspension seat
- Seatbelt
- 12V power source
- Hydraulic pilot control levers with wrist rests
- Switch and harness for beacon light
- Digital Panel

Optional Equipment

- 230 mm steel track (+ 70 kg)
- 1100 mm arm (+150 mm)


SPECIFICATIONS

*Rubber shoe type

				^Rubber snoe type		
Model				Standard version	Long arm version	
Machine w	eight		kg	1650	1700	
Bucket capa	city, std.	SAE/CECE	0.04			
Bucket	with side teeth		mm	450		
width	without	side teeth	mm	400		
Engine	Model			D902		
	Type			Water cooled		
	Outou	+ 1500240	PS/rpm	16/2300		
	Outpu	t ISO9249	kW/rpm	11.8/2300		
	Number	of cylinders	<u>'</u>	3		
	Bore ×	Stroke	mm	72 ×	73.6	
	Displac	cement	СС	898		
Overall length			mm	3545	3550	
Overall height			mm	23	40	
Swivelling speed			rpm	9.1		
Rubber sh	oe widtł	1	mm	2:	30	
Tumbler di	stance		mm	1230		
Dozer size	(width	× height)	mm	990/1240 × 265		
	P1, P2			Variable displacement pump		
Hydraulic pumps	Flow r	ate	ℓ/min	17.3 + 17.3		
	Hydrau	lic pressure	MPa (kgf/cm²)	21.6		
	P3			Gear pump		
	Flow ra	ate	ℓ/min	10).4	
	Hydrau	lic pressure	MPa (kgf/cm²)	18	3.6	
Max.	,	Arm	kN (kgf)	8.5 (865)	7.7 (790)	
digging fo	rce	Bucket	kN (kgf)		(1550)	
Boom swin	Boom swing angle (left/right)		deg	65/58		
Auxiliary circuit	Flow rate		ℓ/min	27.7		
	Hydraulic pressure		MPa (kgf/cm²)	18	3.6	
Hydraulic reservoir			e e	2	!1	
Fuel tank of			19			
Max. travelling		Low	km/h	2	.2	
speed	ıg	High	km/h	4	.1	
Ground contact pressure			kPa (kgf/cm²)	27 (0.28)	28 (0.29)	
Ground clearance			mm	150		
				1		

WORKING RANGE





LIFTING CAPACITY

Over-side (Hack width 1240 mm) KN (ton)												
Lift Point Height		Lift point radius (1.5m)			Lift point radius (2m)			Max. lift point radius				
		Over-front		0	Over-front		Over eide	Over-front		0		
		Blade Down	Blade Up	Over-side	Blade Down	Blade Up	Over-side	Blade Down	Blade Up	Over-side		
2m	950 Arm	-	-	-	2.6 (0.27)	2.6 (0.27)	2.6 (0.27)	-	-	-		
	1100 Arm	-	-	-	-	-	-	-	-	-		
1.5m	950 Arm	4.4 (0.45)	4.4 (0.45)	4.4 (0.45)	3.8 (0.39)	3.4 (0.34)	3.1 (0.32)	-	-	-		
	1100 Arm	-	-	-	3.0 (0.31)	3.0 (0.31)	3.0 (0.31)	-	-	-		
0.5m	950 Arm	-	-	-	5.8 (0.59)	3.0 (0.31)	2.8 (0.29)	2.7 (0.28)	1.5 (0.15)	1.4 (0.14)		
	1100 Arm	-	-	-	5.4 (0.55)	2.9 (0.30)	2.7 (0.27)	2.4 (0.25)	1.3 (0.14)	1.2 (0.13)		
0m	950 Arm	-	-	-	5.5 (0.56)	3.0 (0.30)	2.7 (0.28)	-	-	-		
	1100 Arm	5.0 (0.51)	4.3 (0.44)	3.9 (0.40)	5.3 (0.54)	2.8 (0.28)	2.6 (0.26)	-	-	-		
-0.5m	950 Arm	6.8 (0.70)	4.6 (0.47)	4.2 (0.43)	4.9 (0.50)	2.9 (0.30)	2.7 (0.28)	-	-	-		
	1100 Arm	7.0 (0.71)	4.3 (0.44)	3.9 (0.40)	4.8 (0.49)	2.8 (0.28)	2.5 (0.26)	-	-	-		
-1.5m	950 Arm	4.5 (0.46)	4.5 (0.46)	4.3 (0.44)	3.1 (0.31)	3.0 (0.31)	2.8 (0.28)	-	-	-		
	1100 Arm	4.7 (0.48)	4.4 (0.45)	4.0 (0.41)	3.2 (0.33)	2.8 (0.29)	2.6 (0.26)	-	-	-		

Please note:

- * Over-side figures shown are with crawler fully extended.
- * The lifting capacities are based on ISO 10567 and do not exceed 75% of the static tilt load of the machine or 87% of the hydraulic lifting capacity of the machine.
- * The excavator bucket, hook, sling and other lifting accessories are not included on this table.



- * Working ranges are with Kubota standard bucket, without quick coupler.
- * Specifications are subject to change without notice for purpose of improvement.

★ All images shown are for brochure purposes only.

When operating the excavator, wear clothing and equipment in accordance to local legal and safety regulations.

KUBOTA EUROPE S.A.S.

19 à 25, Rue Jules - Vercruysse -Zone Industrielle - B.P. 50088 95101 Argenteuil Cedex France Téléphone: (33) 01 34 26 34 34

Télécopieur : (33) 01 34 26 34 99

KUBOTA (U.K.) LTD

Dormer Road, Thame, Oxfordshire, OX93UN, U.K.

Phone: 01844-268140 Fax: 01844-216685

KUBOTA Baumaschinen GmbH

Steinhauser Straße 100 D-66482 Zweibrücken Germany Telefon: (49) 0 63 32 - 487 - 312

Fax: (49) 0 63 32 - 487 - 101